

CN57 PARTS LIST

NO.	CODE	Description	NO.	CODE	Description
1	610560	BOLT M6X20(Loctite)	49	110300	BODY
2	630070	SPRING WASHER 6	50	410460	HANDLE GRIP
3	320750	EXHAUST COVER	51	630110	SNAP RING 32
4	610220	BOLT M6X25	52	420540	FILTER
5	110290	CYLINDER CAP	53	620640	SAFETY SPRING
6	520310	GASKET	54	110310	END CAP
7	320460	RING	55	640340	ROLL PIN 3X16
8	410230	PISTON STOP	56	320560	CONTACT PLATE
9	620010	COMPRESSION SPRING	57	320570	TRIGGER
10	510700	O-RING 53X2.65	58	640180	ROLL PIN 3X30
11	510570	O-RING 41.2X3.55	59	322730	SAFETY BRACKET
12	310170	HEAD VALVE PISTON	60	510180	O-RING 5.5X2
13	510510	O-RING 37.5X3.55	61	330010	TRIGGER VALVE BUSHING
14	310280	PISTON	62	510220	O-RING 6.7X1.8
15	322240	DRIVER BLADE	63	510240	O-RING 8.6X1.9
16	410220	CYLINDER SEALING RING	64	620050	TRIGGER VALVE SPRING
17	310290	CYLINDER	65	320110	TRIGGER STEM
18	510680	O-RING 50X2.65	66	510030	O-RING 2.5X1.4
19	520130	CYLINDER SEAL	67	510410	O-RING 18.3X2.65
20	420780	CYLINDER RING	68	640250	STRAIGHT PIN A3X15
21	510850	O-RING 73X3.55	69	512070	O-RING 15.8X1.9
22	410210	BUMPER	70	420090	TRIGGER VALVE CAGE
23	322740	SAFETY	71	420800	MAGAZINE COVER
24	210670	NOSE	72	420240	SPRING HOLDER
25	420180	GUARD COVER	73	620650	MAGAZINE SPRING
26	511250	O-RING 49.5X2	74	321360	NAIL SUPPORT PLATE
27	510090	O-RING 4X1.5	75	420820	MAGAZINE
28	321300	DOOR PIN	76	610220	BOLT M6X25
29	420170	PIN CAP (A)	77	420160	PIN CAP (B)
30	210690	LATCH	78	321370	MAGAZINE PIN
31	621050	LATCH SPRING	79	420830	MAGAZINE POST
32	640080	ROLL PIN 3X12	80	630290	SNAP RING
33	210360	DOOR	81	610330	NUT M6
34	321310	CHECK PAWL PIN	82	610570	BOLT M6X32
35	210370	CHECK PAWL	84	420080	TRIGGER VALVE CAP
36	621080	CHECK PAWL SPRING	85	321380	SIDE PROTECTOR
37	210380	FEED PAWL	86	610210	BOLT M6X22 (Loctite)
38	620610	FEED SPRING	88	640170	ROLL PIN 3X28
39	320210	FEED PAWL PIN	89	630030	FLAT WASHER
40	321320	FEED PISTON	90	640340	ROLL PIN 3X16
41	510300	O-RING 9.7X2.4	91	321540	SPRING SEAT
42	510440	O-RING 20.8X2.4	92	510280	O-RING 9X2
43	620620	FEED PISTON SPRING (B)	93	323180	WASHER
44	321330	SPRING GUIDE	94	324520	TRIGGER SLEEVE
45	620630	FEED PISTON SPRING (A)			
46	410420	FEED PISTON BUMPER			
47	321340	FEED PISTON CAP	P1	D322241	DRIVER UNIT
48	630050	SNAP RING 26	P2	T420091	TRIGGER VALVE

CN57

